




## FORET A GRADINS TRAPBOOR - STEP DRILL



CAPACITE - CAPACITEIT	Hauteur Hoogte Step mm			
		HSS	HSS-TIN	HSS-TIN
4-5-6-7-8-9-10-11-12	4mm	612/1		
4-6-8-10-12	4mm	612/2		
4-6-8-10-12	4mm			47012
6-8-10-12-14-16-18-20	4mm	620/2		
4-6-8-10-12-14-16-18-20	4mm			47020
6-8-10-12-14-16-18-20-22-24-26-28-30	4mm	630/2		
4-6-8-10-12-14-16-18-20-22-24-26-28-30	4mm	47030		47030
12-13-14-15-16-17-18-19-20	4mm	1220/1	11220/1	
20-21-22-23-24-25-26-27-28-29-30	4mm	2030/1	12030/1	
30-31-32-33-34-35-36-37-38-39-40	4mm	3040/1	13040/1	
40-41-42-43-44-45-46-47-48-49-50	4mm	4050/1	14050/1	
50-51-52-53-54-55-56-57-58-59-60	4mm	5060/1	15060/1	
25-28-31-34-37-40-43-46-49-52-55-58	4mm	PG2558		
7-9-12-15-18-21-24-27-30-33-36	4mm	936		
6-9-13-16-19-21-23-26-29-32-35-38	4mm			47038
4-6-8-10-12-14-16-18-20-22	4mm	422		
6-8-10-12-14-16-18-20-22-24	4mm	624		
11,2-37-40-43-46-49-52-55-58-61	5mm	M4		
12,5-15,2-18,6-20,4-22,5-28,3-30,5	4mm	PG721		
12,5-15,2-18,6-20,4-22,5-28,3-37	4mm	PG729		
10,5-12,5-14,5-16,5-18,5-20,5-23,5-25,5-30,5-38,5-40,5	4mm	PG150		
6-7-8-9-10-11-12	10mm	47112		
6-8-10-12-14-16-18-20	10mm	47120		
6-9-12-15-18-21-27	10mm	47127		
6-8-10-12-14-16-18	6mm	618		

### COFFRET 3 FORETS A GRADINS SET 3 TRAPBOREN - KIT 3 STEP DRILLS



**470SET**

HSS + TIN

47012

4-6-8-10-12

47020

4-6-8-10-12-14-16-18-20

47030

4-6-8-10-12-14-16-18-20-22-24-26-28-30

### COFFRET 3 FORETS CONIQUES SET 3 BOREN - KIT 3 SHEET DRILLS



**FTSET**

HSS

3 - 14

8 - 20

16 - 30,5

**FTSETTIN**

3 - 14

8 - 20

HSS + TIN

16 - 30,5